

PRODUCT BULLETIN

Subject: Air Filters-**Inside to Outside** and **Outside to Inside** Flow Direction
 Date: 9-27-05
 Bulletin Number: 05-0927 Air Filter Flow

Original equipment manufacturers may use an air filter housing in various mounting positions and configurations based on limited space and size. One of the common results is the use of the same housing construction in **outside to inside airflow** and **inside to outside airflow** applications.



Inside To Outside Airflow



Outside To Inside Airflow

Champion Laboratories, Inc. / Luberfiner provides several filters which may be installed in either **outside to inside airflow housings** and **inside to outside airflow housings**. It is necessary to note that proper verification and installation of the element is important. Improper installation may result in shortened filter life and/or filter element failure.

	Luberfiner	OE	Fleetguard
	Part Number	Part Number	Part Number
Inside - Out Flow	LAF1815	P524831	AF1821M
Outside - In Flow	LAF2550	P151028	AF1808M
Inside - Out Flow	LAF9472	P129472	AF931M
Outside - In Flow	LAF8044	P148044	AF1837
Inside - Out Flow	LAF9396	P129396	AF954M
Outside - In Flow	LAF8043	P148043	AF1838